



RECHARGEABLE LED TORCH

BP3000 CLASSIC

USER MANUAL



DEAR VALUED CUSTOMER;

Thank you for purchasing the Bull Proof BP3000 Rechargeable LED Torch.

This manual will guide you through the setup and usage of your new torch, ensuring you get the best experience and long-lasting performance. Suitable for a range of applications, this torch is a perfect all-rounder for home, camping, hunting and more.

For inquiries, please contact us using the following methods:

-  Email: sales@bullproof.com.au
-  Phone: (03) 9125 7069
-  Website: www.bullproof.com.au

TABLE OF CONTENTS

04	Product Overview	09	Warranty
04	Package Includes	10	Warranty
05	Features		
05	How to Use		
06	How to Charge		
07	Care and Maintenance		
08	Safety Precautions		

1. PRODUCT OVERVIEW:



2. PACKAGE INCLUDES:

- BP3000 Rechargeable Torch x 1
- Elastic Wrist Strap x 1
- USB to USB-C Charging Cable
- Rechargeable Battery x 1

I 4. FEATURES:

- ✓ 3000 Lumens
- ✓ 350m Beam Distance
- ✓ 3.5+ Hour Operating Time (High Mode)
- ✓ Rechargeable Design
- ✓ IP44 Waterproof Rating
- ✓ Push Button Operation
- ✓ Dimmable settings, with SOS and Flicker Mode

I 5. HOW TO USE:

1. Unbox the product and make sure that all items are present before proceeding with the setup.
2. Unscrew the end cap of the torch and insert the supplied rechargeable battery into the battery compartment. Follow by screwing the cap back on. (Ensure the battery is inserted the correct way).
3. Test your torch by pressing the power button. At the same time, observe the 4 dots next to the power button. This will indicate charge level. (4 blue dots indicates that the torch fully charge).
4. Half click the power button to switch through settings, and full click to turn off.

I 6. HOW TO CHARGE:

Charging Equipment :

You will need the supplied charging cable (or any cable that accepts USB-C), and a charging head to plug into the power point.

Charging Your Torch:

1. Unscrew the head of your torch to reveal the USB-C charging port.
2. Connect your torch to the power source.
3. The blue dots on the side of the power button will indicate charge levels whilst the torch is charging.
4. Once all 4 dots are blue, you can remove the torch of charge and resume normal use until charging is required again.

* If your torch is failing to charge, always check the charging equipment first. If there is a battery issue, please contact us asap.

I 7. CARE AND MAINTENANCE:

Keeping your torch in good condition :

- Don't leave your torch on charge for prolonged periods of time.
- Clean the lens for optimal performance.
- Avoid water, dust and debris from entering the battery compartment.
- Keep your torch in a dry environment.

I 8. SAFETY PRECAUTIONS:

- DO NOT point the flashlight beam in anyones eyes, or your own. This may cause serious eye damage.
- Use only the correct, supplied batteries for your torch.
- Handle the battery with care. Always store in a dry environment and away from excessive hot or cold temperatures.
- CAUTION : The surface of your torch may become warm/hot during use. Avoid direct contact with your skin.

I 9. WARRANTY:

This Limited Warranty covers defects in materials and workmanship in the BP3000 Rechargeable LED Torch under normal use and maintenance, valid for 3 years from the date of purchase.

What is Covered:

- Manufacturing defects that affect the performance of the torch during normal use.
- Issues impacting functionality, including problems with brightness and general performance.
- Defects related to the internal components, including battery.
- Defects to any structural components of the torch.

What is Not Covered:

- Damage resulting from improper handling, dropping, or using the torch in ways not recommended by Bull Proof.
- Unauthorized modifications or repairs made to the product.
- Scratches, blemishes, or damage to the exterior housing and glass due to regular wear and tear.
- Damage caused by exposure to extreme environmental conditions outside the specified operational range or submersion in water beyond the product's water-resistant capabilities.

- Damage resulting from failure to follow proper care and maintenance instructions provided by the manufacturer.



BULLPROOF.COM.AU