

BP5000 XTREME

USER MANUAL



DEAR VALUED CUSTOMER;

Thank you for purchasing the Bull Proof BP5000 Rechargeable LED Torch.

This manual will guide you through the setup and usage of your new torch, ensuring you get the best experience and long-lasting performance. Suitable for a range of applications, this torch is a perfect all-rounder for home, camping, hunting and more.

For inquiries, please contact us using the following methods:

- Email: <u>sales@bullproof.com.au</u>
- 🕖 Phone: (03) 9125 7069
- Website: <u>www.bullproof.com.au</u>



TABLE OF

- 04 | Product Overview
- 04 Package Includes
- 05 Features
- 05 How to Use
- 06 How to Charge
- 07 Care and Maintenance
- 08 Safety Precautions

- 09 | Warranty
- 10 Warranty



USER MANUAL



1. PRODUCT OVERVIEW:



2. PACKAGE

- BP5000 Rechargeable Torch x 1
- Wrist Strap x 1
- USB to USB-C Charging Cable
- Rechargeable Battery x 1



4. FEATURES:

- 5000 Lumens
- 500m Beam Distance
- 6-8 Hour Operating Time
- Rechargeable Design

5. HOW TO USE:

- 1. Unbox the product and make sure that all items are present before proceeding with the setup.
- 2. Unscrew the battery compartent, and remove the paper stopper between the battery and the cap. This will allow your battery to connect and for the torch to operate.

- IP44 Waterproof Rating Push Button Operation
- Dimmable settings, with SOS and Flicker Mode

3. Test your torch by pressing the power button. Each click will take you through a different setting (3 dimmable settings, flicker, and SOS mode).



6. HOW TO CHARGE:

Charging Equipment :

You will need the supplied charging cable (or any cable that accepts USB-C), and a charging head to plug into the power point. If using as a power bank, use the USB port and plug into the item you are charging.

Charging Your Torch:

- 1. Remove the rubber cap on the back of the torch to reveal the USB-C charging port.
- 2. Connect your torch to the power source.
- 3. The power button will light up red whilst charging.
- 4. Once fully charged, the power button will turn green.
- * If your torch is failing to charge, always check the charging equipment first. If there is a battery issue, please contact us asap.



7. CARE AND MAINTENANCE:

Keeping your torch in good condition :

- Don't leave your torch on charge for prolonged periods of time.
- Clean the lens for optimal performance.
- · Avoid water, dust and debris from entering the battery compartment.
- Keep your torch in a dry environment.







8. SAFETY PRECAUTIONS:

- DO NOT point the flashlight beam in anyones eyes, or your own. This may cause serious eye damage.
- Use only the correct, supplied batteries for your torch.
- Handle the battery with care. Always store in a dry environment and away from excessive hot or cold temperatures.
- CAUTION : The surface of your torch can become hot during use. Avoid direct contact with your skin.



9. WARRANTY:

This Limited Warranty covers defects in materials and workmanship in the BP5000 Rechargeable LED Torch under normal use and maintenance, valid for 3 years from the date of purchase.

What is Covered:

- Manufacturing defects that affect the performance of the torch during normal use.
- Issues impacting functionality, including problems with brightness and general performance.
- Defects related to the internal components, including battery.
- Defects to any structural components of the torch.

What is Not Covered:

- Damage resulting from improper handling, dropping, or using the torch in ways not recommended by Bull Proof.
- Unauthorized modifications or repairs made to the product.
- Scratches, blemishes, or damage to the exterior housing and glass due to regular wear and tear.
- Damage caused by exposure to extreme environmental conditions outside the specified operational range or submersion in water beyond the product's water-resistant capabilities.



Damage resulting from failure to follow proper care and maintenance instructions provided by the manufacturer.

USER MANUAL

BULL PROOF

BULLPROOF.COM.AU